



## ACT ENCLOSURE COOLING TECHNICAL NOTE

### How to Calculate Enclosure Component(s) Internal Heat Loads

Motor Drive Example:

#### POWER CONVERSIONS

1 Watt = 3.413 BTUh

1 HP = 745.7 Watts

1 HP = 2,546 BTUh



### Calculating the Internal Enclosure's Heat Load from a Drive

#### EXAMPLE 1:

Known drive efficiency or Watts lost to heat can be estimated if it is not supplied by the manufacturer. Typically 90% to 95% efficient.

*60 HP drive = 60 x 745.7= 44,742 Watts potential power consumption.*

If 95% efficient, and operating at full capacity,  $44,742 \times (1 - 0.95) =$

**2,237 Watts lost to heat or 7,635 BTUh cooling is required**

#### EXAMPLE 2:

*30 HP drive = 30 x 745.7= 22,371 Watts potential power consumption.*

If 95% efficient, and operating at full capacity,  $22,371 \times (1 - 0.95) =$

**1,119 Watts lost to heat or 3,818 BTUh cooling is required**

#### EXAMPLE 3:

*10 HP drive = 10 x 745.7= 7,457 Watts potential power consumption.*

If 95% efficient, and operating at full capacity,  $7,457 \times (1 - 0.95) =$

**373 Watts lost to heat or 1,273 BTUh cooling is required**